

Ender 3 3D Printer


Instructions for assembly

◆ This guide is for the Ender 3 3D printer.


 Select the correct input voltage to match your local mains (220V or 110V)

 Because of software/hardware upgrades and model differences, new revisions may not be listed in this guide.


◆ Detailed instructions for use are available on the SD card.





List 1





List 2





















Step 4 T8 Zm












Step 9 *Don't tighten it too tight









Shenzhen Creality3D Technology CO.,LTD.

Official Website: www.creality3d.com

Company Address: 12F, Building No.3, Jinchengyuan Industrial Area, Huafan Road,

Dalang, Longhua, Shenzhen, Guangdong Province







